




SURROUND VIEW STAKEOUT BLIND

SET UP INSTRUCTIONS

- STEP 1:** Lay blind with the camo facing down. (fig. 1)
- STEP 2:** While pulling the outside corner up, place your palm on the middle of the hub and press down. (fig. 2)
- STEP 3:** Use same method for opposite side. (fig. 3)
- STEP 4:** Set blind upright in desired location. (fig. 4)
- STEP 5:** To reinforce the blind, stake it into the ground through the grommets.



WARNING: Read all instructions and safety warnings and follow them thoroughly. Failure to follow these instructions may result in serious injury or death!

BLIND TEAR DOWN INSTRUCTIONS

STEP 1: Remove stakes.

STEP 2: Lay blind with the camo facing down.

STEP 3: While pulling a rod next to the hub toward you use your opposite hand to push against the center (midline) seam of the blind.

STEP 4: Utilize same method for opposite side.

STEP 5: Roll the blind up and put into bag with hubs facing up.

WARNING: Read all instructions and safety warnings and follow them thoroughly. Failure to follow these instructions may result in serious injury or death!

WARNING: THIS PRODUCT IS NOT FIREPROOF. The fabric will burn if it comes into contact with an open flame or fuel source. DO NOT cook inside a tent; DO NOT Smoke inside a tent; DO NOT store flammable liquids inside a tent. Keep product away from direct flame. Failure to follow this warning may result in serious injury or death!

WARNING: This product is for hunting purposes only! It is not to be used as a camping tent or for any other function. Failure to follow this warning may result in serious injury or death!

WARNING: Do not use devices that produce fumes inside of blind. Vapors and fumes could result in carbon monoxide poisoning, serious injury or death!

WARNING: Do not allow children or adults to use lighted candles, matches, or other sources of fire near this product. Failure to follow this warning may result in serious injury or death!

WARNING: Do not allow material to cover your face. This may result in serious injury, suffocation and death!

WARNING: Do not allow children to use this product without direct adult supervision. Failure to follow this warning may result in serious injury or death!

WARNING: Exercise EXTREME caution when using fuel-powered lanterns or heaters inside a tent and use battery operated lanterns whenever possible. Failure to follow this warning may result in serious injury or death!

TIPS FOR INCREASING PRODUCT LONGEVITY

Always store your blind in a cool dry place and make sure that your blind is completely dry and clean before storing in carrying bag.

Never leave your blind outside for any longer than needed. This material may fade after long periods of time in direct sunlight. Pooling of rain or snow may cause permanent damage to your blind.